

Lab 15: Controller Benchmarks

Time Estimate: 1.5 hours


Training Objective: To investigate the implementation of the watermover

control in the Regional Simulation Model.

Watermover control is obtained directly through Hydrologic Simulation Engine (HSE) watermover controllers and indirectly through the use of assessors in the Management Simulation Engine (MSE). This lab explores the implementation of user-defined controllers, which have been implemented in the HSE, and the implementation of the WMM_assessors to control watermovers.

NOTE:
For ease of navigation, you may wish to set an environment variable to the directory where you install the RSM code using the syntax
setenv RSM <path></path>
For SFWMD modelers, the path you should use for the NAS is:
/nw/oomdata_ws/nw/oom/sfrms/workdirs/ <username>/trunk</username>
<pre>setenv RSM /nw/oomdata_ws/nw/oom/sfrms/workdirs/<username>/trunk</username></pre>
Once you have set the RSM environment variable to your trunk path, you can use \$RSM in any path statement, such as:
cd \$RSM/benchmarks

Training files are currently located in the following directories:



Files for this lab are located in the **labs/lab15_BM1** directory. Additional materials in the directory include:

Activity 15.1 User-Specified Controllers

Overview

Activity 15.1 includes 2 exercises:

- Exercise 15.1.1. Modify <userctrl> in Benchmark 45.
- Exercise 15.1.2. Modify <userctrl> for SR29 in Glades-LECSA RSM

The Regional Simulation Model (RSM) has the capability of implementing user-defined controllers, which are described in Benchmark 45. There are four examples in BM45. These test the use of controllers and supervisors written in either the C++ or the C language. We will investigate the use of controllers in the C++ environment.

Exercise 15.1.1 Modify <userctrl> in Benchmark 45

- In the trunk folder, copy the RSM/trunk/benchmarks/BM45 directory to new directory: BM45a
 - cp -r BM45 BM45a
- 2. Run test.script to ensure BM45a is working correctly
- Run the simple controller (run3x3.xm1) from the RSM Graphical User Interface (RSM GUI)
- 4. Observe the results in t3x3out.dss using the HecDssVue utility
- 5. Select canal S01 head, WM1 control and WM1 flow. Keep the graph




Figure 15.1 Time series of stage, flow and control-setting for the user ctrl

6. Edit the run file (run3x3.xml) and turn off the controller cid="101"

```
<!-- Watermovers to be controlled -->
<watermovers>
 <!-- discharge from canal segment 1 -->
 <hq_relation wmID="1" id="1" label="">
    <hq>
     0.0
     495.0 0.0
499.0 -50.0
     500.0 -150.0
     501.0 -300.0
     510.0 -1000.0
 </hq>
</hq_relation>
 <!-- inflow into canal segment 4 -->
 <hq_relation wmID="2" id="4" label="">
     <hq>
     0.0
            0.0
     490.0 1000.0
     495.0 500.0
     499.0 250.0
     500.0 150.0
     501.0 50.0
     510.0 0.0
 </hq>
</hq_relation>
</watermovers>
<controller id="1">
 <!-- Controller for discharge from segment 1 -->
 <varIn name="Segment4"><segmentmonitor id="4" attr="head"/></varIn>
 </userctrl>
</controller>
<controller id="2";</pre>
 <!-- Controller for pumping into segment 4 -->
 <userctrl cid="102" label="Segment 4 Ctrl" wmID="2" control="on"</pre>
  libType="C" module="./User_C.so" func="Segment4_Control" ctrlMin="0.0" ctrlMax="1.0" >
    <varIn name="Segment1"><segmentmonitor id="1" attr="head"/></varIn>
    <varIn name="Segment4"><segmentmonitor id="4" attr="head"/></varIn>
 </userctrl>
</controller>
```

Figure 15.2 The watermovers and control functions used with user-specified controllers

- 7. Rerun model, display results and compare to the previous results
 - How does the stage behave?
- 8. Edit the userctrl.cc file and change the lower control value from 500 to 499.5

The controller behavior is described in a C++ that sets the control variable. In this case the variables "Segment1_Control" and "Segment4_Control" are set in the userctrl.cc file (Fig. 15.2). The user-controller is implemented using the <controller> block in the file (Fig 15.3)

- Recompile the user-control library by executing the makefile script using the "make" command
- 10. Rerun the model and compare current results to previous results

- 11. Change the output gain "controlOut" from 1.0 to 0.60 and run the model
 - · Compare the results to previous results
- 12. Change the controlOut to 6.0 and observe the results

```
// Function Segment1_Control for control of watermover into segment 1
extern "C" double Segment1 Control( map<string, InputState*> *lpInputStateMap ) {
  string func = "Segment1 Control";
 double controlOut = 0.;
 double segment1Head = GetVarIn( func, "Segment1", lpInputStateMap );
// These are not used, but illustrate how to get values from XML input
 // Provide control function based on input state variable
 if ( segment1Head > 502. )
   controlOut = 1
  else if ( segmentlHead > 501. )
    controlOut = 0.5
 else if ( segment1Head > 500. )
   controlOut = 0.2;
 else
    controlOut = 0.;
 return controlOut;
```

Figure 15.3 The userctrl.cc file used to set rules for controlling structure

Activity 15.2 WMM-Assessor (Benchmark 63b)

Overview

Activity 15.2 does. This activity includes 1 exercises:

• Exercise 15.2.1. Run WMM-Assessors in BM 63b.

Exercise15.2.1 Run WMM-Assessors in BM 63b

User-defined controllers can be used for specific structures but are rarely used in the current versions of the subregional models. Effective for controlling the behavior of individual structures, user-defined controllers have proven expensive to scale-up to the subregional or regional implementations.

In this exercise you will find the user-defined controllers and describe how they are used.

In the /RSM/data/glades_lecsa directory, find the glades-controllers
 xml

HINT



Find the <controller> block in the run_81.xml file.

- 2. Find the controllers for the SR29 structures:
 - What are the inputs to the controller?
 - What is the file with the control variables?
 - What does the control rule in SR29 seasonalctrl.cc do?
 - What watermovers does this control?
 - · What does the control behavior look like?
 - What are the flow values for the structures?
- 3. Run the model and graph the flow data for the SR29 structures.




Figure 15.4 Simulated discharge at the SR29 weirs

- 4. Edit the SR29_seasonalctrl.cc and change the dryseason control to 0.2.
- 5. Recompile the control file using the instructions in SR29_seasonalctrl.cc.



The compilation instructions are at the top of the file.

6. Run the model using RSM GUI and compare the results to the previous run.

Activity 15.2 WMM Assessor (Benchmark 63b)

Overview

Activity 15.2 does. This activity includes 1exercise:

• Exercise 15.2.1. Run WMM-Assessors in BM 63b.

The WMM_Assessor uses assessors to determine the amount of water from the Hydrologic Simulation Engine (HSE) that needs to be moved to or from a water control unit to meet the water supply (ws) needs or flood control (fc) requirements for each basin. The user-entered mse_units and mse_nodes are used to construct the <mse_network>. The wmm_assessor <WMM> determines the required management of the structures <mse_struc> from "off" to full "on" at each managed structure, based on the requirements for each structure.

This benchmark was designed to test the behavior of the WMM_Assessor. In order to understand the structure of the mse_network, map out the network manually:

- In the benchmark folder (/RSM/trunk/benchmarks) copy Benchmark 63b to the BM63b1 directory. All work for this activity will be completed in the lab16_mse/BM63b directory.
 - cp -r ./RSM/trunk/benchmarks/BM63b ./RSM/trunk/benchmarks/BM63b1
- 2. List the mse_network.xml file.
- 3. Create a diagram of the mse_network connecting the mse_units using the mse_nodes.
 - List the water supply maintenance levels next to each <mse unit>
 - List the maximum discharge capacity next to each <mse_node> (structure)
 - List the flood control level for each reach. (Look at <mse_node> openings)
- 4. Construct a plot that shows the discharge behavior of <mseStruc> S9 and S8.

The flow is calculated as follows:

Q= dischar Δh^a

- The default for a is 0.5 (if not specified)
- 5. Add the **<runDescriptor>** element to the **control** section.
 - hseMaxIteration = "144"
 - runDescriptor = "forest"
- 6. Run Benchmark 63b using the RSM GUI.

7. Observe the following data using HecDssVue from the RSM GUI:

- Cell heads (cellheads.dss) Find the cell locations and WCU using the Groundwater Modeling System? (GMS) graphic for mesh and network, Fig. 15.1 in the Answer-lab15 file
 - · What do these values indicate?
- Segment heads (segmentheads.dss)
 - Which WCUs become flooded?
- Structure flows (structureflows.dss)
- Nodeflows
 - Plot the QWS and QFC for a couple of nodes. What do you see?
- Lake
- Bcflows (These are the flows into or out of the domain. This may be important where you are trying to produce net outflow, balance or net inflow.)
- Iterations

The Management Simulation Engine (MSE) sets the flows at the structures and these are imposed on the Hydrologic Simulation Engine (HSE) matrix solution. The Regional Simulation Model iterates the HSE solution until the HSE flows converge with the MSE flows. This plot shows the number of iterations.

- 8. Replace the marsh Hydrologic Process Module (HPM) with an irrigated land HPM.
- Change the HPM from <layer1nsm> (forest) to <afsirs> (turf) by substituting the following code (Fig. 15.5).
- 10. Change the runDescriptor in the **<control>** block to "turf".
- 11. Save the model as wmm assessors b.xml.

```
<hpModules>
  <indexed file="hpm.index">
    <hpmEntry id="1">
      <afsirs>
        <afcrop label="turf" id="15" j1="01-01" jn="12-31" depth1="12"</pre>
depth2="24">
          <kctbl>
             1.00 1.00 1.00 1.00 1.00 1.00
             1.00 1.00 1.00 1.00 1.00 1.00
          </kctbl>
          <awdtbl>
             0.50 0.50 0.50 0.50 0.50 0.50
             0.50 0.50 0.50 0.50 0.50 0.50
          </awdtbl>
        </afcrop>
        <afirr label="MULTIPLE SPRINKLER" wtd="2.5">
          <irrmeth id ="4" eff="0.85" arzi="1.0" exir="0.7"></irrmeth>
          <irrmgmt label = "DROUGHT" trigcode="2" value="100"></irrmgmt>
        <afsoil label="SANDY LOAM SOILS" depth="96" minwc="0.09"
maxwc="0.15" cond="1">
        </afsoil>
      </afsirs>
    </hpmEntry>
  </indexed>
</hpModules>
```

Figure 15.5 Title

- 12. Run the model using the RSM GUI.
- 13. Observe the results compared to the previous run as "forest" by opening the following DSS files:
 - cellheads.dss
 - segmentheads.dss
 - nodeflows.dss
 - iterations.dss
- 14. Use HecDssVue and plot the "forest" time series with the "turf" time series.
 - How have the cell and segment heads changed from the forest HPMs?
 - How have the nodeflows changed?
 - How has the number of iterations changed?
- 15. Change the water management level in each WCU by adding a "reserve level" to the WCUs at the upper end of the regional system. (This will allow water to be delivered to the lower reaches to allow those WCUs to maintain higher water tables.)

16. In the mse_network.xml file add and replace the following lines to mse_unit name=

"Reach#":

Figure 15.6 Title

Add to Reach1:

```
<resLevel name="reach1 reserve"> <const value="3.5"/> </resLevel>
```

Add to Reach2:

```
<resLevel name="reach2 reserve"> <const value="3.0"/> </resLevel>
```

Add to Reach3:

```
<resLevel name="reach3 reserve"> <const value="2.75"/>
</resLevel>
```

- 17. Save the file as **mse_networkb.xml**.
- 18. Change <mse_network> in wmm_assessorb.xml to
 xml="mse_networkb.xml".
- 19. Change the **runDescriptor** in the **<control>** block to "**reserve**". Save the file.
- 20. Run mse_network.xml and observe the results:
 - · cellheads.dss
 - segmentheads.dss
 - nodeflows.dss
 - How have the cell and segment heads changed?
 - How have the nodeflows changed?




Figure 15.7 Title

Index

_Assessor (Benchmark 63b), 8	discharge behavior, 8
"forest" time series, 10	dryseason control, 7
"reserve level", 10	environment variable, 2
"reserve", 11	executing the makefile script, 4
"turf" time series, 10	flood control (fc), 8
<afsirs>, 9</afsirs>	flood control level, 8
<control>, 9, 11</control>	flow data, 6
<control> block, 11</control>	flow values, 6
<controller> block, 4, 6</controller>	forest HPMs, 10
<a 101",="" 4<="" href="mailto:right-ri</td><td>glades-controllers xml, 6</td></tr><tr><td><mse_network>, 8, 11</td><td>Glades-Lower East Cost Service Area, 6</td></tr><tr><td><mse_node>, 8</td><td>Glades-Lower East Cost Service Area (LECSA), 6</td></tr><tr><td><mse unit>, 8</td><td>Glades-Lower East Cost Service Area (LECSA)</td></tr><tr><td><mseStruc>, 8</td><td>subregional model, 6</td></tr><tr><td><runDescriptor>, 8</td><td>GMS, 9</td></tr><tr><td>assessors, 8</td><td>Groundwater Modeling System, 9</td></tr><tr><td>balance, 9</td><td>Groundwater Modeling System? (GMS) graphic for</td></tr><tr><td>Bcflows, 9</td><td>mesh and network, 9</td></tr><tr><td>benchmark, 8</td><td>HecDssVue, 3, 9, 10</td></tr><tr><td>Benchmark 45, 3, 6</td><td>HecDssVue utility, 3</td></tr><tr><td>Benchmark 63b, 8</td><td>HPM, 9</td></tr><tr><td>Benchmark 63b (BM63b), 8</td><td>hpmbud, 2</td></tr><tr><td>benchmarks, 2</td><td>HSE, 1, 8, 9</td></tr><tr><td>BM45, 3, 6</td><td>HSE flows, 9</td></tr><tr><td>BM45a, 3</td><td>HSE solution, 9</td></tr><tr><td>BM63b, 8</td><td>hseMaxIteration, 8</td></tr><tr><td>BM63b1, 8</td><td>Hydrologic Process Module, 9</td></tr><tr><td>budtool, 2</td><td>Hydrologic Simulation Engine, 1, 8, 9</td></tr><tr><td>C++, 4, 6</td><td>Hydrologic Simulation Engine (HSE), 1, 8</td></tr><tr><td>canal S01 head, 3</td><td>Hydrologic Simulation Engine (HSE) matrix</td></tr><tr><td>Cell heads, 9</td><td>solution, 9</td></tr><tr><td>Cell heads (cellheads.dss), 9</td><td>Hydrologic Simulation Engine (HSE) watermover</td></tr><tr><td>cellheads.dss, 9, 10, 11</td><td>controllers, 1</td></tr><tr><td>compilation instructions, 7</td><td>Implement the user-controller, 3</td></tr><tr><td>control, 8</td><td>implementation of the watermover control in the</td></tr><tr><td>control behavior, 6</td><td>Regional Simulation Model, 1</td></tr><tr><td>control file, 7</td><td>implementation of the WMM assessors to control</td></tr><tr><td>control rule, 6</td><td>watermovers, 1</td></tr><tr><td>control variable, 4</td><td>implementation of user-defined controller in Glades</td></tr><tr><td>control variables, 6</td><td>Lower East Cost Service Area (LECSA) subregiona</td></tr><tr><td>control watermovers, 1</td><td>model, 6</td></tr><tr><td>controller, 6</td><td>implementation of user-defined controllers, 1</td></tr><tr><td>controller behavior, 4</td><td>implementing user-defined controllers, 3, 6</td></tr><tr><td>Controller Benchmarks, 1</td><td>inputs, 6</td></tr><tr><td>controller cid=" td=""><td>inputs to the controller, 6</td>	inputs to the controller, 6
controllers, 3, 6	irrigated land, 9
controlling the behavior of individual structures, 6	irrigated land HPM, 9
controlOut, 5	iterations, 9, 10
current versions of the subregional models, 6	Iterations, 9
determine the amount of water from the Hydrologic	iterations.dss, 10
Simulation Engine (HSE) that needs to be moved to	Lake, 9
or from a water control unit to meet the water	LECSA, 6
supply (ws) needs or flood control (fc) requirements	lower control value, 4
for each basin 8	make 4

make" command, 4	SR29 structures, 6
makefile script, 4	SR29_seasonalctrl.cc, 6, 7
managed structure, 8	stage, 4
management of the structures <mse_struc>, 8</mse_struc>	structure of the mse_network, 8
Management Simulation Engine, 1, 9	subregional model, 6
Management Simulation Engine (MSE), 1, 9	subregional models, 6
map out the network by hand, 8	test the behavior of WMM-Assessor, 8
marsh, 9	The userctrl.cc file used to set rules for controlling
marsh Hydrologic Process Module (HPM), 9	structure, 5
maximum discharge capacity, 8	The watermovers and control functions used with
MSE, 9	User-specified controllers, 4
MSE flows, 9	Time series of stage, flow and control-setting for the
mse_network, 8	user_ctrl, 3
mse_network.xml, 11	use of assessors, 1
mse network.xml file, 8	use of assessors in the Management Simulation
mse_nodes, 8	Engine (MSE) to control watermover, 1
mse_units, 8	use of controllers and supervisors written in either
net inflow, 9	C++ or the C language, 3
net outflow, 9	use of the controllers in the C++ environment, 6
nodeflows, 10, 11	user-control library, 4
Nodeflows, 9	user-controller, 4
nodeflows.dss, 10, 11	userctrl.cc file, 4, 5
note, 2	user-defined controller, 6
output gain "controlOut", 4	User-defined controller Benchmark 45 (BM45), 3
produce net outflow, 9	user-defined controllers, 1, 3, 6
Q= dischar Δh^a , 8	User-defined controllers, 6
QFC, 9	Water Control Unit, 9
QWS, 9	Water Control Units, 9
rain, 2	water management level, 10
Regional Simulation Model, 9	water supply (ws), 8
regional system, 10	water supply maintenance levels, 8
RSM Graphical User Interface, 3	watermover control, 1
RSM Graphical User Interface (RSMGUI), 3	Watermover control, 1
RSMGUI, 3, 7, 8, 9, 10	watermovers, 6
run file, 4	WCU, 9, 10
runDescriptor, 8, 9, 11	WCUs, 10
segment heads, 10, 11	We will be investigating the use of the controllers in
Segment heads, 9	the C++ environment, 3
Segment1_Control, 4	WM1 control, 3
Segment4_Control, 4	WM1 flow, 3
segmentheads.dss, 9, 10, 11	WMM_Assessor, 8
setenv, 2	wmm_assessor < WMM >, 8
simple controller, 3	WMM_assessors, 1
Simulated discharge at the SR29 weirs, 7	WMM-Assessor, 8